



## 88-310 Removal and installation of cable control for engine hood

### Removal


1 Unscrew outer screw on cover under instrument panel.



2 Push the two clips on cover toward the rear by means of a plastic wedge and lower cover.




3 Unscrew both screws on handle.




4 Disconnect hood cable control on handle.

**5** Pull cable control out of bracket on wheel house and loosen plastic tape.




**6** Pull hood cable control out of clips under radiator reinforcement.



**7** Loosen counter-nut and push pin of clips out of lower half of lock.

**8** Pull out hood cable control in forward direction.



## Installation

**9** For installation proceed vice versa while adjusting hood cable control at lower half of lock free of play.